



## PARTS LIST

MODEL: AF01 / 02 / 03 / 05 / 06 / 61

ITEM	DESCRIPTION	TOOL MODEL.	PART NO.	Q'TY	ITEM	DESCRIPTION	TOOL MODEL.	PART NO.	Q'TY	ITEM	DESCRIPTION	TOOL MODEL.	PART NO.	Q'TY
1	Anvil	AF01	AF01001	1	23	Dowel Pin		AF01023	1	60	Pusher Spring		AF01060	1
		AF02/61	AF02001		24	Dowel Pin		AF01024	1	61	Screw		AF01061	1
		AF03/06	AF03001		25	Piston O-Ring		AF01025	1	62	Flex-Nut		AF01062	2
		AF05	AF05001		26	Piston		AF01026	1	63	Spacer		AF01063	1
2	Blade	AF01	AF01002	1	27	Piston Big O-Ring		AF01027	1	64	Screw		AF01064	2
		AF02	AF02002		28	Washer		AF01028	1	67	O-Ring		AF01067	2
		AF03/06	AF03002		29	Spring Washer		AF01029	2	68	Valve Body		AF01068	1
		AF05	AF05002		30	Piston Cap Screw		AF01030	1	69	O-Ring		AF01069	1
		AF61	AF61002		31	Cap		AF01031	1	70	O-Ring		AF01070	2
3	Blade Guide	AF01	AF01003	1	32	Cap Big O-Ring		AF01032	1	73	Pin		AF01073	1
		AF02	AF02003		33	Lock Screw		AF01033	1	74	Pusher Hook		AF01074	1
		AF03/06/61	AF03003		34	Lock Screw		AF01034	1	75	L Spring		AF01075	1
		AF05	AF05003		35	Screw		AF01035	4	84	Flex Loc-Nut		AF01084	1
4	Pusher	AF01/02/03/06/61	AF01004	1	36	O-Ring		AF01036	1	85	Magazine Pad		AF01085	1
		AF05	AF05004		37	Valve Piston		AF01037	1	86	Brake Plate		AF01086	1
5	Side Plate L.H.	AF01/02/03/06/61	AF01005	1	38	Hanger Yoke		AF01038	1	88	Pad Roll	AF03/61	AF03088	4
		AF05	AF05005		39	Roller Bearing		AF01039	2			AF05	AF05088	
6	Side Plate R.H.	AF01/02/03/06/61	AF01006	1	40	Hanger Yoke Screw		AF01040	1			AF06	AF06088	
		AF05	AF05006		41	Hanger Pin		AF01041	2	93	Air Inlet		AF01093	1
7	Top Plate		AF01007	1	43	Screw		AF01043	2	200	Piston Assy.		AF01200	1
8	Yoke		AF01008	1	47	Long Screw		AF01047	2	201	Housing Assy.		AF01201	1
9	Yoke Pin(B)		AF01009	1	48	Trigger		AF01048	1	202	Valve Assy.		AF01202	1
10	Yoke Pin(S)		AF01010	1	49	Trigger Pin		AF01049	1	203	Yoke Assy.		AF01203	1
11	O-Ring (flat)		AF01011	1	50	Washer		AF01050	6	204	Suspension Hanger		AF01204	1
12	O-Ring		AF01012	1	51	Flex-Nut		AF01051	2	205	Hanger Support		AF01205	1
13	O-Ring		AF01013	1	52	Screw		AF01052	2	206	Hanger Assy.		AF01206	1
14	Front Plate		AF01014	1	53	Screw	AF01/02/61	AF01053	6	207	Pusher Bracket Assy.		AF01207	1
15	Link PIN		AF01015	1			AF03/05/06	AF01053	2	208	Pusher Assy.	AF01/02/03/06/61	AF01208	1
16	Link		AF01016	2		AF03053	4	AF05	AF05208					
17	Roller		AF01017	1	54	Screw		AF01054	2	210	Bottom Magazine Assy.		AF01210	1
18	Trigger Valve Lever		AF01018	1	55	Long Screw		AF01055	1	211	Magazine Assy.	AF01/02	AF01211	1
19	Valve Sleeve		AF01019	1	56	Pin		AF01056	2			AF03/61	AF03211	
20	O-Ring		AF01020	2	57	Screw		AF01057	1			AF05	AF05211	
21	Valve Piston		AF01021	1	58	Washer		AF01058	2			AF06	AF06211	
22	Valve Spring		AF01022	1	59	Flex-Nut		AF01059	2					