





AC01H AC02H AC03H
AC04H AC05H



PARTS LIST FOR AC01H - AC05H

ITEM	DESCRIPTION	MODEL	PART NUMBER	Q'TY	ITEM	DESCRIPTION	MODEL	PART NUMBER	Q'TY	ITEM	DESCRIPTION	MODEL	PART NUMBER	Q'TY		
10	Screw		AC01H010	4	47	Feeder Blade	AC01H	AC01047	1	76	Magazine Shoe	AC01H	AC01M076	1		
11	Nylon Nut		AF01C111	8			AC02H	AC02047				AC02H-05H	AC02M076			
12	E-Ring		AD21036	3			AC03H/04H	AC03047		AC01H	AC01077	1				
13	Washer		AC01H013	2			AC05H	AC05047			AC02H-05H		AC02077			
21	Nylon Nut		AC01021	2	48	Piston Rod	AC01H	AC01048	1	79	Washer		AC01079	2		
30	Support Set		AC01H030	1			AC02H	AC02048		AC03H-05H	AC03048	86	Plate Screw		AC731086	1
32	Clevis		AC01H032	1			49	Roller Pin				AC01049	2	101	Pusher Assy.	AC01H
33	Arm Link		AC01H033	2	50	Lower Jaw	AC01H	AC01050	1	112	Arm Screw		AC01H112	4		
35R	Side Plate (Right)		AC01H35R	1			AC02H	AC02050		150	Washer(Thin)		AC01H150	1		
35L	Side Plate (Left)		AC01H35L	1			AC03H	AC03050		151	Washer		AC01H151	2		
40	Upper Jaw	AC01H	AC01040	1			AC04H	AC04050		152	T Pin (L)		AC01H152	2		
		AC02H	AC02040		AC05H	AC05050	153	T Pin (S)		AC01H153	1					
		AC03H	AC03040		51	Pusher Set		AC01H051	1	155	T Nut	AC01H	AC01H155	1		
		AC04H	AC04040		64	Screw		AC01064	1			AC02H-05H	AC02H155			
41	Jaw Bushing		AC01041	2	65	Lever		AC01H065	2	160	Handle		AC01H160	2		
43	Latch Pin Clip		AC01043	1	66	Bracket		AC01H066	1	202	Piston Rod Assy.	AC01H	AC01202	1		
44	Latch Spring	AC01H-04H	AC01044	1	67	Nylon Nut		AC01067	1			AC02H	AC02202			
		AC05H	AC05044		69	Roll Pin		AC01069	1			AC03H/04H	AC03202			
45	Latch	AC01H/02H	AC01045	1	70	Pusher Spring		AC01070	1	AC05H	AC05202					
		AC03H/04H	AC03045		73	Magazine	AC01H	AC01M073	1	205	Pusher Assy.	AC01H	AC01H205	1		
		AC05H	AC05045				AC02H-05H	AC602073				AC02H-05H	AC02H205			
46	Roller	AC01H/03H-05H	AC01046	4	74	Jaw Bolt		AC01074	2	206	Magazine Assy.	AC01H	AC01M206	1		
		AC02H	AC02046		75	Magazine Spring	AC01H	AC01075	1			AC02H-05H	AC602206			
							AC02H-05H	AC02075								